

INSTALLATION INSTRUCTIONS

for Mechanical Thermostat Kit: 0848-062-K for H137C Series Hot Cabinets

Unplug power cord from power outlet

1. Remove Front Black Trim.
(2 black screws on front and one screw on top).
2. Remove Top Cover. (5 screws on top and 6 screws on back of the unit).
3. Remove Hot Unit.
 - a) 4 screws on the front of the Hot Unit.
 - b) Remove 7 screws from the top of the Hot Unit.
See attached sketch.
4. Remove clip and spacer to free the thermostat bulb. (2 screws).
5. Remove thermostat knob and 2 screws from the front of Hot Unit.
6. Replace thermostat and assemble Hot Unit back in reverse order.

